

# Cabin Air Filter Installation Instructions

Interior ventilation filters are located behind the glove box compartment door.

1. Open glove box door. Push inwards on the glove box door to release the door stops. Swing glove box door completely down. (See Figure 1)
2. Depress the lower tab from the filter housing cover and remove cover. (See Figure 2)
3. Slide the first filter out towards you. Lift the second filter upwards and then slide the second filter out of housing. (See Figure 3)
4. Installation is in the reverse order of removal.

*Approximate install time: 5 minutes*




Figure 1




Figure 2




Figure 3

**atp**  
professional auto parts®

1300PrattBoulevard  
Elk Grove Village, Illinois 60007  
Tech Help Line: 1-800-528-6695  
[www.atp-inc.com](http://www.atp-inc.com)

Form No. CF190