

Cabin Air Filter Installation Instructions

Battery cooling filter is located behind the driver's side seat inside the driver's side panel.

1. Turn ignition to the off position. You may have to enter through the rear passenger side door to locate the filter access panel.




Figure 1

2. Remove filter housing access panel behind the driver's side seat. (See Figure 1)

3. Push the tabs located on each side of the filter and remove from housing. (See Figure 2)




Figure 2

4. Installation is in the reverse order of removal.

*Approximate Installation Time:
10 minutes.*

atp
professional auto parts®

1300PrattBoulevard
Elk Grove Village, Illinois 60007
Tech Help Line: 1-800-528-6695
www.atp-inc.com