

Cabin Air Filter Installation Instructions

Interior ventilation filter is located underneath the passenger side dashboard.

- 1. Remove (4) to (5) filter housing cover screws. Remove vent filter housing cover. (See Figure 1)**
- 2. Pull down on the filter's tab and remove filter straight down.**
- 3. Installation is in the reverse order of removal.**

Approximate install time: 10 minutes




Figure 1

atp
professional auto parts®

1300 Pratt Boulevard
Elk Grove Village, Illinois 60007
Tech Help Line: 1-800-528-6695
www.atp-inc.com