

Cabin Air Filter Installation Instructions

Interior ventilation filter is located inside the cooling unit behind the glove box door.

1. **Open glove box door.**
Remove both of the glove box stops located on both sides of the inner part of the glove box door. Remove the right arm clip located on the right side of the door assembly and allow the glove box door to swing down. (See Figure 1)




Figure 1

2. **Remove the cooling unit cover and slide filter out towards you.** (See Figure 2)
3. **Install filter, cooling cover and glove box door in the reverse order of removal.**




Figure 2

Approximate Installation Time:
5 Minutes

atp

professional auto parts®

1300 Pratt Boulevard
Elk Grove Village, Illinois 60007
Tech Help Line: 1-800-528-6695
www.atp-inc.com