

Cabin Air Filter Installation Instructions

Interior ventilation filters are located on the underside of the hood.

1. Open and secure the hood.
2. Remove each filter housing cover screws. (See Figure 1)
3. Open the filter housing covers and remove the filters. (See Figure 2)
4. Install both filters, close the filter housing covers and re-install screws.

*Approximate Installation Time:
5 Minutes*




Figure 1




Figure 2

atp
professional auto parts®

1300 Pratt Boulevard
Elk Grove Village, Illinois 60007
Tech Help Line: 1-800-528-6695
www.atp-inc.com