

Cabin Air Filter Installation Instructions

Interior ventilation filter is located underneath passenger side cowl panel.

- 1. Raise and secure hood. Position the wiper arms up. Remove the wiper arm assemblies retaining nuts and remove the arms. (See Figure 1)**
- 2. Remove the (15) cowl panel retainers and remove the cowl panel. (See Figure 2)**
- 3. Open the filter housing cover and slide filter out of housing. (See Figure 3)**
- 4. Installation is in the reverse order of removal.**




Figure 1




Figure 2




Figure 3

Approximate install time: 20 minutes

atp

professional auto parts®

1300 Pratt Boulevard
Elk Grove Village, Illinois 60007
Tech Help Line: 1-800-528-6695
www.atp-inc.com