

# Cabin Air Filter Installation Instructions

Interior ventilation filter is located underneath passenger side cowl panel.

- 1. Open and secure hood. Remove (6) cowl panel retaining screws and remove the cowl panel. (See Figure 1)**
- 2. Remove the filter from the (3) release catches. Swing the filter forward towards the front of the vehicle then upwards. (See Figure 2)**
- 3. Installation is in the reverse order of removal.**

*Approximate install time: 10 minutes*




Figure 1




Figure 2

**atp**  
professional auto parts®

1300 Pratt Boulevard  
Elk Grove Village, Illinois 60007  
Tech Help Line: 1-800-528-6695  
[www.atp-inc.com](http://www.atp-inc.com)