

# Cabin Air Filter Installation Instructions

Interior ventilation filter is located underneath cowl panel, underneath hood.

- 1. To remove cowl panel, windshield wiper arms must be removed. Remove the cowl panel to gain access to the filter housing. (See Figure 1)**
- 2. Release (2) filter release tabs at the top of the filter. Swing filter forward towards the front of the vehicle and release the (2) lower release tabs remove the filter. (See Figure 2)**
- 3. Installation is in the reverse order of removal.**

*Approximate install time: 15 minutes*




Figure 1




Figure 2

**atp**  
professional auto parts®

1300 Pratt Boulevard  
Elk Grove Village, Illinois 60007  
Tech Help Line: 1-800-528-6695  
[www.atp-inc.com](http://www.atp-inc.com)