


Cabin Air Filter Installation Instructions

The interior ventilation filter is located underneath a panel near the passenger side of the windshield.

1. Open the hood and locate the interior ventilation filter door.
2. Open the door and pull out the filter. **Tip:** push the retaining tab on the filter housing to release the filter.
3. Install the new filter. Start installing by pushing the tab on the filter housing.
4. Close the interior ventilation door.

Tip: this filter folds; fold the filter in the way it would sit after installation, with the longer part on the top. Push the top fold in first and guide the lower portion into its slot as more of the top portion is inserted in its slot.

Approximate Installation Time: 25 Minutes



atp
professional auto parts®

1300PrattBoulevard
Elk Grove Village, Illinois 60007
Tech Help Line: 1-800-528-6695
www.atp-inc.com

Form No. GA3-CF24